




## Power Bank Charger

3000mAh

## User Manual

### Power Bank Layout



### Suitable for

- iPhone/iPod
- Most smartphones including Samsung, HTC, Motorola, Nokia, LG, Sony, BlackBerry, Huawei, Asus, Telstra, Doro & more
- GPS devices, digital cameras, portable hand-held gaming consoles
- Portable Bluetooth devices such as fitness tracker or headset
- eReaders such as Kindle, Kobo & Sony

### Features

- 24 x Anti-Skid suction cups to securely attach to your phone
- Sticks to almost any smooth surfaced phone or phone case
- Simple and fast to stick and remove
- Rechargeable more than 800 times
- Four LED indicators to show remaining capacity
- Includes short micro USB cable for charging your Android phone
- Includes additional micro USB cable for charging the power bank
- Built-in over charging and short circuit protection
- Advanced 3000mAh Lithium-Polymer battery
- Input: DC5V 1.5A
- Output: DC5V 1A
- Charging Time: 5 to 6 hours
- Size: 107mm (L) x 58mm (W) x 13.5mm (H)
- Weight: 92g

### To Charge Power Bank

Charge via USB Wall Charger




Charge via Computer USB Port



- Using the included USB cable, connect the larger USB connector to an AC wall adapter or USB port on a computer
- Connect the smaller micro USB connector to the input port on the power bank
- During charging the LEDs will flash to show charging status
- When charging is complete all four LED's will be permanently on

### To Charge Phone or USB Device



- Using your phone or other USB device's charging cable, connect the USB Type A connector to the USB Output on the power bank
- Connect the other end of the cable to your device
- Charging should start automatically. If it doesn't, press the on/off button
- If your phone or device uses a standard micro USB Type B connector then you can also use the included cable to charge your device
- When your phone or device is fully charged, the power bank will stop charging to prevent over charging or over heating

### To Check Remaining Capacity

- Press the On/Off button and the LEDs will light to show remaining capacity
- The LEDs will turn off automatically after about 10 seconds

LED ● On / ○ Off / ● Flashing	Remaining Capacity
● ○ ○ ○	Less than 5%
● ● ○ ○	5% to 25%
● ● ● ○	25% to 50%
● ● ● ●	50% to 75%
● ● ● ●	75% to 100%

### Important Safety Instructions

- To maximize battery life span, fully charge power bank before first use for 5 to 6 hours
- Store power bank in a cool and dry place.
- Do not store power bank in hot or humid environment
- Operating temperature should be between -10c to 45c
- If power bank is not used for long periods of time, you should charge and discharge once every three months
- When charging a device, the power bank may feel warm, this is a normal operating condition and should not be cause for concern
- In normal conditions, the battery performance will decline over several years
- Do not dispose of power bank in heat or fire
- Do not clean power bank with harmful chemicals or detergents
- Misuse, dropping or excessive force may cause product damage

All rights reserved. Any information printed here is subject to change without notice. iPhone and iPod are trademarks of Apple Inc., registered in the U.S. and other countries. All other brand names, trademarks, registered trademarks and copyrights are the property of their respective owners. Comsol and the Comsol logo are trademarks of Comsol Pty Ltd

www.comsol.com.au

